





Simple Assembly Instructions



1		4PCS
2		16PCS
3		16PCS
4		2PCS
5		8PCS
6		8PCS
7		2PCS
8		6PCS
9		8PCS
A		4PCS
B		4PCS
C		2PCS
D		1PCS
E		8PCS
		8PCS
		16PCS
		1PCS
		6PCS
		2PCS



Instruction

- 1) Take the canopy out of the box carefully and place on dry surface (sand, grass, or the surface).
- 2) please have at least 4 people helping with the assembly, in order to avoid the damage of surface.
- 3) Secure tent in windy conditions by using the rope that is located on each side of the canopy and hammering stakes into the ground at a 30 degree angle to balance the sides of tent. It is the owner's responsibility if the tents are set-up and damaged during these conditions.
- 4) DO NOT ASSEMBLE TENTS IN RAIN, SEVERE WIND OR SNOWY WEATHER CONDITIONS, BECAUSE THIS WILL DAMAGE YOUR TENT. It is the owner's responsibility if the tents are set-up and damaged during these conditions.
- 5) Store your canopy/tent in a cool dry place when not in use.